## Lab: Installing and configuring Server Core

Scenario Your team in the IT department at Adatum Corporation just purchased a new server that has no operating system. The team decides to install Windows Server 2016 Datacenter Evaluation in Server Core mode to test Server Core functionality. Your task is to perform the installation and configuration of this server. You will name it LON-SVR6, give it a static IP address of 172.16.0.26, and join it to the Adatum.com domain with all other default settings.

**Objectives** After completing this lab, you will be able to: \* Install the Server Core option for Windows Server 2016. \* Configure Server Core.

Lab Setup - Estimated Time: 60 minutes - Virtual machines:20740C-LON-DC1 and 20740C-LON-SVR6 - User name: Adatum\Administrator - Password: Pa55w.rd - - For this lab, you will use the available virtual machine environment. Before you begin the lab, complete the following steps: 1. On the host computer, start Hyper-V Manager. 2. In Hyper-V Manager, click 20740C-LON-DC1, and then in the Actions pane, click Start. 3. In the Actions pane, click Connect. Wait until the virtual machine starts. 4. Sign in by using the following credentials: 1. User name: Adatum\Administrator 2. Password: Pa55w.rd 5. In Hyper-V Manager, right-click 20740C-LON-SVR6, and then select Connect. In the virtual machine connection window, click Media, point to DVD Drive, and then click Insert Disk. 6. Browse to D:\Program Files\Microsoft Learning\20740\Drives, select WinServer2016\_1607.iso, and then click Open.

## **Exercise 1: Installing Server Core**

**Scenario** You determine that Server Core offers you the best installation option and decide to evaluate a server that uses Server Core. The main task for this exercise is as follows: 1.Install Windows Server 2016 Datacenter Evaluation on LON-SVR6.

Task 1: Install Windows Server 2016 Datacenter Evaluation on LON-SVR61. In the 20740C-LON-SVR6 Virtual Machine Connection window, click the Start icon. 2. When LON-SVR6 starts Windows Setup, install Windows Server 2016 Core by using the Windows Server 2016 Datacenter Evaluation option. 3. Use the Custom option rather than the Update option, accepting all other default values and license agreements. 4. Use Pa55w.rd for the Administrator's password. 5. Verify that when the installation is complete, the Command Prompt window on LON-SVR6 opens with a C:\Users\Administrator> prompt.

**Results:** After completing this exercise, you will have successfully installed the Windows Server 2016 Core operating system on LON-SVR6.

# Exercise 2: Completing post-installation tasks on Windows Server 2016 Core

Scenario You must now complete the installation of Server Core by configuring the post-installation settings and joining it to the Adatum.com domain. You will also install the DNS Server role. The main task for this exercise is as follows:

1. Use Windows PowerShell and Sconfig.cmd to configure the settings of Server Core.

Task 1: Use Windows PowerShell and Sconfig.cmd to configure the settings of Server Core 2. Open Windows PowerShell on LON-SVR6. 3. Use the \$env:computername and Get-NetIPAddress cmdlets to display the LON-SVR6 host name and IPv4 address information. 4. Note that the name is random and that the address is automatically derived from a DHCP Server. 5. Run the Sconfig.cmd tool on LON-SVR6. Use the tool to set the following: 1. IP Address settings: 1. Address: 172.16.0.26 2. Subnet Mask: 255.255.0.0 3. Default Gateway: 172.16.0.1 4. Preferred DNS Server: 172.16.0.10 2. Join the Adatum.com domain and use Adatum\administrator credentials. 3. Rename the computer LON-SVR6 and use Adatum\administrator credentials. 4. Restart the computer. 5. After LON-SVR6 starts, sign in as Administrator with the password Pa55w.rd. 6. Start Windows PowerShell, and then use the \$env:computername and Get-NetIPAddress cmdlets to display the LON-SVR6 host name and IPv4 address information. 7. Note that the name is LON-SVR6 and that the address is 172.16.0.26. 8. Type the following, and then press Enter:

#### Install-WindowsFeature DNS

**Results**: After completing this exercise, you will have successfully configured the domain and network settings of Server Core and install an additional role.

## **Exercise 3: Performing remote management**

Scenario Now that you added the DNS Server role to Server Core or LON-SVR6, you want to explore configuring the DNS settings and configuration by using GUI tools on other Windows Server with Desktop Experience systems. The main tasks for this exercise are as follows: 1. Enable remote management with Server Manager. 2. Add LON-SVR6 to DNS Manager on LON-DC1 and then add the Adatum.com zone to LON-SVR6 as a secondary zone. 3. Examine the new zone information on LON-SVR6.

Task 1: Enable remote management with Server Manager1. On LON-DC1, in Server Manager, addLON-SVR6 to the Computer list. 2. Open DNS Manager, and then addLON-SVR6 as a name server in the Adatum.com zone. 3. In DNS Manager, allow zone transfers to all name servers, and then set Notify to 172.16.0.26.

Task 2: Add LON-SVR6 to DNS Manager on LON-DC1 and then add the Adatum.com zone to LON-SVR6 as a secondary zone 1. In DNS Manager, on LON-DC1, add LON-SVR6 as an additional DNS server by using the Connect to DNS Server window. 2. In DNS Manager, add the Adatum.com zone as a secondary zone on LON-SVR6, using LON-DC1 as the master DNS server. 3. Refresh DNS Manager, and then verify that LON-SVR6 has the Adatum.com zone information and resource records from LON-DC1.

Task 3: Examine the new zone information on LON-SVR61. Return to LON-SVR6. 2. Use the dnscmd command to enumerate the zones and note the type of zone for Adatum.com:

Dnscmd /enumzones

3. Use **dnscmd** to enumerate the zones on LON-DC1 and note the type of zone for Adatum.com:

Dnscmd LON-DC1 /enumzones

4. Display the DNS client server address by using Windows PowerShell:

#### Get-DnsClientServerAddress

5. Set the LON-SVR6 DNS server address, replacing the X with the actual interface index number from step 4:

Set-DnsClientServerAddress -InterfaceIndex X -ServerAddresses ("172.16.0.26", "172.16.0

6. Verify the results. Use the Windows PowerShell command from step 4.

**Results:** After completing this exercise, you will have configured the DNS Server settings on LON-SVR6remotely.

#### Task 4: Prepare for the next module

After you finish the lab, revert the virtual machines to their initial state by completing the following steps: 1. On the host computer, switch to the **Hyper-V Manager** console. 2. In the **Virtual Machines** list, right-click **20740C-LON-DC1**, and then click **Revert**. 3. In the **Revert Virtual Machine** dialog box, click **Revert**. 4. Repeat steps 2 and 3 for **20740C-LON-SVR6**.